



CEILING PANEL INSTALLATION INSTRUCTIONS

1. Z-Clips are attached to the rear of the panel at the factory.
2. Installer is to determine appropriate position for hardware & ceiling panel. Allow a minimum of 1" space between the panel top and intersecting wall surfaces or structures to allow panel to slide into position.
3. Ceiling hardware is to be fastened to the substrate by the installer using appropriate fasteners.
4. Installer should have clean hands or wear clean gloves to avoid soiling panel fabric.
5. Locking Pins / Slide Prevention Pins to be located on three sides or open sides of panels to prevent panel movement / falling.

NOTE: These instructions are only a guide. As there may be many variable field conditions, the responsibility for recognizing these conditions and adjusting for them lies with the installer.