

INSTALLATION INSTRUCTIONS - TONEWOOD™ MICRO-PERFORATED PANELS

1. Installer is to determine the appropriate position for mounting furring strips to the wall using the appropriate fasteners. (Furring strips and fasteners are to be selected and supplied by the installer.)
NOTE: Furring strips need to meet or exceed the thickness of the TheaterBlack™ panels.
2. Fasten TheaterBlack™ to the wall using the appropriate fasteners (by others). TheaterBlack™ panels are provided at a nominal 4'x8' and will need to be cut to size to fit in between the furring strips.
3. Z-clips and wall brackets will arrive with your panel order. Installer is to determine appropriate positioning for mounting both the z-clips to the backs of the panels and the wall brackets to the furring strips on the wall using the appropriate fasteners.
NOTE: A minimum 1" vertical engagement clearance must be provided between the top of the panel and the ceiling or intersecting surface. This allows for the panels to be slid down to engage with the wall brackets.
4. ToneWood™ Micro-Perforated panels are to be pressed gently against the TheaterBlack™ and/or furring strips and slid down, engaging the Z-clips into the wall brackets.
NOTE: Lateral movement is possible. The use of base support brackets (by others) is recommended to help support the weight of the panel and keep them in alignment.

NOTE: These instructions are only to be used as a guide. As there are many variant field conditions, it is the responsibility of the installer to recognize these conditions and compensate for them appropriately.

