

## STICK PIN & WASHER INSTALLATION INSTRUCTIONS

Perforated Stick Pins with washers are used to fasten fiberglass panels to walls or ceilings.

The 2" x 2" perforated steel base allow the Stick Pin to be attached to the wall or ceiling surface with nails or screws in conjunction with Pin Adhesive.

The Pin Adhesive is applied to the back of the Stick Pin prior to attaching with nails or screws to the surface. This creates a solid bond when the adhesive penetrates the perforated holes.

Once the Stick Pin is set in place, the fiberglass panel can be pierced onto the Stick Pin.

A Self Locking Washer is then placed onto the Stick Pin to securely hold the panel in place. The excess Stick Pin length can then be trimmed.

