

Maintenance & Cleaning - AcoustiShell™

1. All Acoustishells are subject to soiling and wear due to the environment. A regular maintenance program initiated at the earliest possible time after installation will go a long way toward preventing soil and dirt build-up or staining of the AcoustiShell(s). Extra cleaning and preventative maintenance is necessary in areas adjacent to air-conditioning or air-return vents.
2. Cleaning agents used on the surface should be a mild pH neutral water-based cleaner. Windex or 409 or Warm water with a mild soap can be used for cleaning with a clean, non-abrasive, white t-shirt cloth.
3. Temperature should be maintained between 50°F and 85°F. Humidity should be maintained between 20% and 50% for maximum life of the AcoustiShells.
4. The panel should never be placed in water or allowed to become wet inside.
5. Test any cleaning agents on a piece on the side of the Acoustishell before using on the face.
6. Grease or oil should be wiped off immediately upon contact. Remove excess grease. Use hot water and mild soap to remove any remaining material.
7. Do not handle the panels any more than necessary. Avoid bending or flexing the AcoustiShell.
8. Avoid contact with any sharp edges on material which may cause a puncture of the surface.
9. Avoid excessive heat or moisture as they may affect the finish and adhesives.