



HANDLING OF AVL WOOD PRODUCTS

- Products shall be delivered to the project site in the original, labeled, unopened packages.
- Keep packages of components unopened to acclimate to the building conditions
- All panels and diffusers must be stored and installed at temperatures between 60°F and 90°F, and relative humidity between 35% and 45%.
- Materials shall be stored flat and level to avoid bowing.
- Products must be allowed to stabilize on site for 72 hours prior to installation.

AVL Systems, Inc.

5540 SW 6th Place, Ocala, FL 34474 USA

Toll Free: 800-ACUSTIC | Local: 352-854-1170 | Fax: 352-854-1278

Website: <https://AVLonline.com> | Email: info@AVLonline.com